

Technical Bulletin #20 Load Cell Earth Modification.



Attach the M5 Ring Tag on the 820mm Earth Strap to the back Load Cell fixing and run it through the Load Cell Flexi-Chain.



Bring it out of the flexi chain and route it under the Scale Box.



Attach the M6 Ring Tag of the 820mm Earth Strap along with the 1260mm Earth Strap Tag to the M6 tapped hole at the front RHS of the Balance Assembly using an M6 X 12 Button Head screw.



Route the 1260mm Earth Strap under the Scale Box, behind the connectors as shown, and into the large Flexi-Chain.



Secure the opposite end of the 1260mm Earth Strap using an available M6 fixing inside the Flexi-Chain Box. Take up any slack in the cable in the box.