


Extend and Retract Switches on an Mkii Carriage.



The balance is moved from Left (Extend) to Right (Retract) by the Air Piston.

In either position the Switch Activator pin must depress the relevant switch otherwise the Stepper Motor will not run and move the Carriage into the Dispenser.