

Formulator™ Integra

Contents:

- 1 x base unit**
- 1 x weigh plate**
- 1 x monitor (optional)**
- 1 x IEC mains lead**
- 1 x software CD-ROM**
- 1 x PS/2 Mouse**



1. Remove the outer packaging and place the weigh plate gently onto the four rubber locators on the top of the base unit.
2. Connect the VGA cable to the MONITOR connector on the back of the base unit, shown on the diagram below.
3. Connect the other end of the VGA cable to the VGA socket located in the rear of the monitor.
4. Connect the PS/2 Mouse to the MOUSE connector shown below.
5. Connect the mains lead into the 'power input' socket on the back of the base unit; the power supply is auto sensing 110/230V 50/60Hz.
6. Plug in and switch on at the mains first. Then switch the base unit on by pressing the red 'Soft On/OFF' button at the back.
7. Switch the monitor on using the switch on the front panel.
8. Your Integra will now boot into Windows98se®.

